

NOTES:

2) OPERATING TEMPERATURE: -40°C TO +80°C.

NOT TO BE REMOVED.

7) GAS SPRING TO BE ASSEMBLED WITH END FITTINGS COMPLETELY FASTENED.

8) GREASE TO BE INCLUDED INSIDE THE BALL SOCKET OF THE END FITTINGS.